Steering Wheel (07-0004)

1: Place the Steering Wheel Insert inside the Steering Wheel.

2: Use the 2-1/2" lag screw and washer to fasten the Steering Wheel to the board. Do not over-tighten the lag screw or the Steering Wheel will not turn.

(Note: board must be at least 2" thick so that the lag screw does not penetrate the other side.)

3: Place the Steering Wheel Cap over the center of the Steering Wheel and snap it into the Steering Wheel Insert.

Steering Wheel
(11-1/2" diameter x 3-1/2" deep)
(Grip is 1" diameter)

2"
Minimum

4 x 4 board shown
(not included)

Steering Wheel Insert

Washer
(20mm o.d. x 10.5mm i.d)

Lag Screw
(9.5mm o.d. x 62mm L)

Steering Wheel Cap

Please note: Steering Wheel is intended for make-believe-play by children.

FOR RESIDENTIAL USE ONLY
FOR CHILDREN AGES 3-11